
BIOS Professional

FS711
ROTARY KITCHEN TIMER



TIMER FEATURES


- LED digital display
- One hand operation
- Rotation time adjustment
- Memory function
- Volume adjustment (3 Levels) up to 90dB
- Dimmer function
- Magnetic and anti-slip backing
- 3 x AAA batteries included

COUNTING DOWN

- Rotate the outer silver dial to set your desired time. Rotate the dial clockwise to increase (+), or counterclockwise to decrease (-) time
- After countdown time is set, press the **[o]** button once to commence timer
- Press the **[o]** button to pause the countdown, press and hold the **[o]** button again to clear the time to 00:00
- When the countdown timer reaches 00:00, an alarm will sound and the LED screen will flash
- The buzzer alarm will last 60 seconds before shutting off automatically
- Press the **[o]** button to stop the buzzer alarm manually
- To recall the last countdown time, press the **[o]** button once
- Press and hold the **[o]** button again to reset the screen to 00:00

VOLUME CONTROL


- To adjust the volume level slide the switch up or down, located on the right side of the back of the timer



LED BRIGHTNESS

- To adjust the LED brightness, slide the switch up or down, located on the left side on the back of the timer

Status	Normal Mode	High Brightness Mode
Standby Mode (When timer is on but not set)	LED dims from high to low brightness after 5 seconds, then turns off after an additional 5 seconds	LED remains at high brightness for 5 seconds before turning off
During countdown or count up	LED dims after 5 seconds from high brightness	LED remains at high brightness until the end of set time



COUNTING UP

- Press and hold the **[o]** button to reset the time on the dial to 00:00
- Press the **[o]** button again and the timer will start counting up (max: 99 minutes : 55 seconds)
- Press the **[o]** button to pause the count up
- Press and hold the **[o]** button to clear the timer to 00:00

WARRANTY

The Rotary Kitchen Timer has a 1 year warranty to be free of manufacturing defects in materials and workmanship under normal applications of the original owner. If this product becomes inoperable due to defect and requires correction, return the product with all component pieces and proof of purchase to the address listed below. This warranty does not cover any shipping/transport costs. This warranty does not apply if the product is subject to misuse, neglect, rough handling or damage.
Ship the unit prepaid and insured (at owners option) to:

Thermor Ltd.
Attn: Returns Department
16975 Leslie Street
Newmarket, ON L3Y 9A1
www.biosprofessional.com
Email: thermor@thermor-ins.com

Paper Papier FSC www.fsc.org FPO
MANUFACTURED BY / FABRIQUÉ PAR :
THERMOR LTD.
16975 LESLIE STREET
NEWMARKET, ON L3Y 9A1
MADE IN CHINA / FABRIQUÉ EN CHINE
WWW.BIOSPROFESSIONAL.COM